


Fender Mustang Pickup Switching Configurations


JTM Creations © 1999





The Fender Mustang has four different sound choices:

- 1.) Neck pickup only
- 2.) Bridge pickup only
- 3.) Both pickups "ON Phase-in" (this is the same as the "in-between positions" on Stratocasters).
- 4.) Both pickups "ON Phase-out"



The "+" and "-" only comes into play when both pickups are "ON." Practical speaking, choices 1 and 3 are the only "usable" settings.





1. Neck pickup "ON"



2. Bridge pickup "ON"



3. Both pickups "ON Phase-in"



4. Both pickups "ON Phase-out"

